

Automatic Movement

This manual contains important information on the safe and efficient operation of the watch. Please read the manual seriously before you using the movement.

Function:

1. Automatic movement
2. Hour, minute and second hands at center
3. Week indicator at 9H
4. Date indicator at 3H
5. Year and Month windows at 12H
6. Fly wheel at 6H

Adjustment:

1. Crown at position1: hand-winding
2. Crown at position2: second hand stop; time adjustment
3. Corrector A: Year indicator correcting
4. Corrector B: Month indicator correcting
6. Corrector D: Date indicator correcting

